AUDYSSEY

# Wireless Speakers

## Product Manual

Version 1.3

# Table of Contents


WELCOME..... 3

WHAT'S IN THE BOX..... 3

TOUR THE AUDYSSEY WIRELESS SPEAKERS..... 4

CONNECTING YOUR WIRELESS SPEAKERS..... 5

BLUETOOTH® WIRELESS TECHNOLOGY ..... 6

STREAMING AUDIO VIA BLUETOOTH WIRELESS TECHNOLOGY..... 7

PLAYING AUDIO USING THE 3.5 MM (1/8-INCH) AUDIO INPUT JACK..... 8

LISTENING WITH HEADPHONES..... 9

VOLUME CONTROL & STANDBY MODE..... 9

UNDER THE HOOD..... 10

AUDIO TECHNOLOGIES INSIDE..... 11

TROUBLESHOOTING..... 12

SAFETY..... 14

WARRANTY..... 15

# Welcome

Audyssey® knows audio. Our sound-optimizing technologies are used in studios, movie theaters, home theaters and automobiles. These Wireless Speakers use Audyssey EQ®, Audyssey Dynamic EQ® and Audyssey BassXT® in a feature-rich product to provide a powerful and intuitive all-in-one audio solution for your media. It works with tablets, smart phones and iPods® and, if needed, can be wired to nearly anything with a 3.5 mm (1/8-inch) audio output jack.

With the Audyssey Wireless Speakers you can:

- Stream music wirelessly without tying up your phone. Check email, send text messages or use your favorite app without missing a beat.
- Get deeper bass with BassXT than any other compact speaker.
- Enjoy music at soft volume levels with Audyssey Dynamic EQ.
- Overcome common room distortion with Audyssey EQ for clear balanced sound.
- Connect your iPod, tablet or laptop with Bluetooth wireless technology.

## What's in the Box

Audyssey Wireless Speakers
Power Supply
3.5 mm (1/8 in) audio cable
Speaker interconnect cable
Power supply
Warranty booklet
Quick Start Guide

*Note: Your Audyssey Wireless Speakers will come with region-specific power cords to match the requirements of your country.*

# The Audyssey Journey

Audyssey engineers start by designing loudspeaker drivers, electronics and the speaker cabinets from the ground up. We optimize these components so they work in unison with our audio algorithms then tune and rigorously test the complete system for clear and natural playback. The speakers adapt in real time to reproduce music or movies accurately. From our labs to your home, Audyssey technology is delivering better sound.

# Tour the Audyssey Wireless Speakers




## RIGHT SPEAKER FRONT

1. Volume control & standby knob
2. Tweeter (high frequency driver)
3. Woofer (bass driver)
4. 3.5 mm headphone output
5. Power LED

## RIGHT SPEAKER BACK

6. Bluetooth pairing button
7. Bluetooth LED
8. Power cable plug
9. 3.5 mm audio input jack (stereo)
10. Passive bass radiator
11. Speaker interconnect cable jack



## CABLES

12. Power cable
13. 3.5 mm stereo audio cable
14. Speaker interconnect cables

# Connecting Your Wireless Speakers



1. Before plugging your speakers in to an AC wall socket, connect them to each other using the speaker interconnect cables **[14]**.



2. Connect the supplied power cable **[12]** to the Wireless Speakers' power cable plug **[8]**.
3. Connect the other end of the power cable **[12]** to an AC wall socket. Notice the power LED **[5]** will glow a solid red. Your speakers are now in standby mode.
4. Turn on your speakers. Press and release the front of the standby knob **[1]**. The power LED is now a solid green.

Note: You can open the speaker interconnect cable jack **[11]** by pressing down on the spring-loaded button above each jack. Twist the ends of the speaker interconnect cables **[14]** so the strands are not loose. The wires and jacks are color coded; match the colors and plug them in.

Note: For proper stereo playback, make sure the speaker with the volume control **[1]** is placed on the right.

**JUST A NOTE**

The Audio Dock Air comes in 2 versions, 110 V and 220 V. When using the Audio Dock Air in a country of a different voltage than your unit, you must use a Step Up or Step Down voltage transformer of the appropriate wattage.

# Bluetooth® Wireless Technology Setup

Pairing and connecting using Bluetooth wireless technology is very easy. The Wireless Speakers provide visual and audible feedback so you know they're paired and connected.

Press the Bluetooth pairing button **[6]** on the back of the right speaker. You will hear a short two-note beep and the Bluetooth LED **[7]** will begin flashing green to indicate discoverable mode. You can now pair your device to the Wireless Speakers.

Enable Bluetooth on the device you are pairing and, from its Bluetooth settings, select "Audyssey Wireless Speakers."

When you hear a single beep you'll know that the device has successfully paired. The Bluetooth LED **[7]** will also turn a solid green. Some devices may ask for a password and if yours does just enter "0000."

### JUST A NOTE

A few seconds may elapse before the Wireless Speakers appear as "Audyssey Wireless Speakers" in the device list—they may come up first as "Headset" or something similar.

You are now able to stream audio to the Wireless Speakers.

If you have more in-depth questions about Bluetooth pairing, please check out the Troubleshooting portion of this manual.

Note: The Wireless Speakers will remember the last device they've been connected to. So, after you leave the Wireless Speakers' Bluetooth range and become disconnected, when you reenter the Wireless Speakers' range the Speakers (if they are on) will automatically reconnect to your device. And the Speakers will chime with a single beep just to let you know that your audio is ready to stream.

# Streaming Audio via Bluetooth® Wireless Technology

You can stream audio to the Wireless Speakers from any device equipped with the Bluetooth A2DP profile. Most smart phones, portable audio players, laptops and tablets have this capability. If you're unsure whether your device does, please see your device's owner's manual.

First, make sure you've paired your music player to the Wireless Speakers using Bluetooth wireless technology. If you haven't already done this, see the instructions in the "Bluetooth Wireless Technology Setup" section of this manual.

The following demonstrations for streaming music to the Wireless Speakers use an iPhone® and an Android phone as examples. If you're using a different device, your procedure will be similar—but you may need to generalize these specific examples.

Before Selecting "Audyssey Wireless Speakers"

After Selecting "Audyssey Wireless Speakers"

### JUST A NOTE

On your iPhone, you'll notice the output device icon to the right of the volume bar will be blue, indicating Bluetooth wireless technology streaming. Tapping this icon will allow you to toggle audio playback between your Speakers and your device. To toggle in an Android, you will use the same pull up menu from the example on the next page.

Here on the left you see an iPhone that has been connected with the Wireless Speakers but is not using Bluetooth wireless technology to play audio. By touching the output device icon and selecting the Wireless Speakers from the list, you will let the iPhone know to stream audio to the Speakers via Bluetooth wireless technology as show here on the right.

Any music you play now will be streamed to the Wireless Speakers.




Playing Music through your Phone




Playing Music through Audyssey Wireless Speakers

In the Android example above the Android phone has also already been connected to the Wireless Media Speakers. By using the pull up menu and selecting "Via Bluetooth" the phone's audio will be streamed to the Speakers.

# Playing Audio Using the 3.5 mm (1/8-inch) Audio Input Jack



On the back of the right Wireless Speaker you'll find the 3.5 mm (1/8-inch) audio input jack **[9]**. Just plug your audio source in here and press play.

Note: Some computer headphone or line-level outputs may have abnormally high signals. If you hear audio distortion from your computer, simply turn down its volume level.

### JUST A NOTE

The audio input jack on the back of the Wireless Speakers operates simultaneously with the Bluetooth input, so you can listen to two audio sources at the same time. Now you can listen to music from your iPod while still hearing your computer system sounds through the Wireless Speakers.

# Listening with Headphones



To listen to music over headphones, plug the headphones into the 3.5 mm headphone output **[4]** on the front of your Wireless Speakers. To adjust the headphone volume, just use the volume control **[1]**.

**JUST A NOTE**

Before listening to music over headphones, adjust the volume control [1] to a low level. Once your headphones are plugged into the 3.5 mm headphone output [4], slowly begin turning up the volume to a comfortable listening level in order to protect your ears.

# Volume Control

## Adjusting the Volume

To adjust the volume or mute the sound, use the volume control **[1]** on the Wireless Speakers. Clockwise will make your Speakers' output louder and counter-clockwise will make it quieter. Turn it counter-clockwise the entire way to mute your Wireless Speakers.



**JUST A NOTE**

In order to take full advantage of Audyssey's Dynamic EQ we recommend you maximize the level of the output signal coming from the source (set the volume at MAX) and make any adjustments to the volume using the Wireless Speakers' volume control.

## Standby Mode

You can place the Wireless Speakers in standby mode by pressing the standby knob **[1]**. One click toggles the Speakers between standby and on. You can tell the difference by the power LED **[5]**. Red is Standby. Green is On.

**JUST A NOTE**

After two hours The Wireless Speakers will automatically go into standby mode. They can be turned back on by simply pressing the standby knob [1].

# Under the Hood

The Audyssey Audio Dock Air speaker systems feature high quality construction and components.

- Two .75 in tweeters
- Two 3 in woofers
- Two 4 in passive bass radiators
- Audyssey EQ
- Audyssey BassXT
- Audyssey Dynamic EQ

## Electroacoustic

| | |
|---|---|
| Maximum SPL @1m | Approximately 106 dB SPL using fantastic rock-n-roll program material |
| Cabinet | Two sealed enclosures |

## Physical I/O

| | |
|---|---|
| Audio | 3.5 mm (1/8-inch) stereo input; 3.5 mm(1/8-inch) stereo output |

## Bluetooth

| | |
|---|---|
| Profiles | A2DP, HFP |
| Pairing Name | Audyssey Wireless Speakers |
| Pairing Code | 0000 |

## Power

| | |
|---|---|
| Input Voltage | $100V_{AC}$-$120V_{AC}$ (50/60 Hz) Factory set based on location<br>$220V_{AC}$ -$240V_{AC}$ (50 Hz) Factory set based on location |
| Power Draw | Quiescent: 5.5 W<br>Max 18 W |

## Physical

| | |
|---|---|
| Dimensions | 4.9” (w) x 6.8” (d) x 9” (h); 12.5 cm (w) x 17.3 cm (d) x 23 cm (h) |
| Boxed Weight | 7 lbs; 3.2 kg |

## Devices

| | |
|---|---|
| Works With | Bluetooth® enabled devices<br>All iPhone® models<br>All iPad® models<br>All iPod® models<br>Smart phones<br>Tablets<br>Laptops<br>Game consoles |

# Audio Technologies Inside

Our innovative audio technologies, used worldwide in millions of theaters, homes and cars, are packed into the Wireless Speakers to make all of your content sound better than you ever expected.

**Audyssey EQ:** We designed these Speakers under a variety of listening conditions with an array of program material to make sure you enjoy full rich sound, right out of the box.

**Audyssey BassXT:** We don't use gimmicks. We monitor the input in real time and extend the performance of the drivers to bring you deeper bass than has ever been available out of such small speakers.

**Audyssey Dynamic EQ:** These Speakers maintain bass and rich sound at low volumes by continuously monitoring your content to make vocals intelligible and background detail clear at every level.

# Troubleshooting

Refer to the table below for solutions to common problems.

**NEED MORE HELP?**

Visit audyssey.com/support for FAQs and support forums or call 877.655.4901.

| QUESTIONS | ANSWERS |
|---|---|
| I can't pair my Audyssey Wireless Speakers with my Bluetooth device. What are some common fixes? | You should make sure your Audyssey Wireless Speakers are discoverable. Press the Bluetooth pairing button **[6]** and confirm that the Bluetooth LED **[7]** is flashing. You will also hear a short two-note beep to confirm that your device is discoverable and can be paired.<br>Check the password. Some devices require them and if your device is one of them the password should be "0000." Make sure the Bluetooth capability of your device is turned on.<br>It's possible that your Bluetooth device is out of range. Try moving it closer to the Wireless Speakers.<br>Make sure your Bluetooth device supports streaming audio. (Check its owner's manual for specific information on pairing and Bluetooth functionality.)<br>Try resetting your Audyssey Wireless Speakers' Bluetooth settings. To do this simply press and hold the Bluetooth pairing button **[6]** for 10 seconds.<br>*Note: Resetting your Wireless Speakers will delete all of its stored pairing information. You will need to re-pair all of your devices.* |
| My paired Bluetooth device won't connect. What can I try? | Make sure your Wireless Speakers are disconnected from other devices. If another Bluetooth device is currently streaming to your Speakers they will not connect. *(Pressing the Bluetooth pairing button [6] will disconnect the Speakers from any device.)*<br>If your Bluetooth device has already been paired to your Wireless Speakers you may also try removing the Speakers from the devices list of Known Devices. Then start at the beginning of the pairing process in this manual and pair them again. |
| My Wireless Speakers aren't playing audio from my Bluetooth device. What should I check? | Make sure the volume control **[1]** on your Audyssey Wireless Speakers is up.<br>Make sure the volume on your Bluetooth device is set to maximum volume and that it is playing audio.<br>Make sure your Bluetooth device has Audyssey Wireless Speakers selected as the output sound device. It may be paired but not connected.<br>Your Bluetooth device may also be out of range. Try moving it closer to the Audyssey Wireless Speakers. |
| What's the Bluetooth code for pairing? | "0000" (four zeros). For instructions on how to pair your device with the Wireless Speakers using Bluetooth, please see the Owner's Manual section on Bluetooth pairing. |
| How much time do I have to pair my device to the Wireless Speakers once I've entered Bluetooth pairing mode? | Three minutes. If you don't pair a device within three minutes, the Wireless Speakers will exit Bluetooth pairing mode. You can exit Bluetooth pairing mode manually simply by pressing the Bluetooth button. Once you've paired a device, the Wireless Speakers will exit Bluetooth pairing mode automatically. |
| I'm getting poor audio quality. What can I do to improve the audio quality during Bluetooth streaming? | If you're having drop-outs in the audio you should first try moving your Bluetooth device closer to the Audyssey Wireless Speakers to see if that helps. Also try turning off any sources of electromagnetic interference. Also try turning off or relocating any sources of electromagnetic interference and devices that operate near the 2.4 GHz RF band as they can cause interference with Bluetooth technology.<br>If you notice a difference in audio quality between Bluetooth streaming and connecting via the 3.5 mm audio input jack **[9]**, then your device may be limiting the Bluetooth data rate. Check your device's manual for tips or information on improving its audio quality. |
| I just reset my Wireless Speakers and am now having trouble re-pairing a device. Why? | After you've reset your Wireless Speakers you must remove them from any previously paired item's list of "Known Devices" (or something similar).<br>Example: If your iPhone was previously paired with your Speakers, before reconnecting to that iPhone you must go into the phone's Bluetooth options and remove the Wireless Speakers from the "Known Devices" list. Once the iPhone has "forgotten" the Speakers it can be paired with them again. |
| What's the difference between Bluetooth pairing vs. connecting? | Pairing means the Wireless Speakers and your device have been "introduced" to each other and have the potential to connect.<br>Connecting a paired device means putting it to use. In this case, playing music.<br>*Note: Only one device at a time can be connected to the Wireless Speakers via Bluetooth, but up to 9 devices can be paired.* |
| Can the Wireless Speakers play music from a source without Bluetooth? | Yes. You can use the 3.5 mm (1/8-inch) aux audio connection for audio devices, such as computers, CD/DVD players or smart phones. If your particular device does not have a 3.5 mm (1/8-inch) stereo jack, you can use an adapter cable corresponding to the connector you have. Just be sure you get a stereo version of the adapter. |
| Can the Wireless Speakers use batteries? | No. The Wireless Speakers requires AC power from a wall outlet. |

| QUESTIONS | ANSWERS |
|---|---|
| Can I use the Wireless Speakers with my iPad®? | Sure. Watch a movie on the iPad and stream the sound to the Wireless Speakers. |
| Is it easy to mount the Wireless Speakers on a wall? | No. We did not intend for the Wireless Speakers to be mounted on a wall. The passive bass radiator needs some space to breathe. |
| Can I use the Wireless Speakers for VoIP calls? | Yes. You can use it with VoIP applications on your computer. The Wireless Speakers will stream all of the audio from a connected source. So if you're talking to a friend on Skype®, the voice you would normally hear through the computer's internal speakers will be streamed to your Wireless Speakers. |
| How do reach Audyssey Technical Support for other questions or issues? | Visit: www.audyssey.com/support |

## CONTACT

Audyssey Laboratories, Inc.
350 S. Figueroa Street, Suite 233
Los Angeles, CA 90071
www.audyssey.com

# Safety

**IMPORTANT SAFETY INSTRUCTIONS FOR THE USA, CANADA, AND MEXICO**

**Read these instructions.** All the safety and operating instructions should be read before the product is operated.

**Retain these instructions.** The safety and operating instructions should be retained for future use.

**Heed all warnings** on the product and in the owner's guide.

**Follow instructions.** All operating and use instructions should be followed.

Do not use this apparatus near water or moisture. For example, do not use this product near a bathtub, washbowl, kitchen sink, laundry tub, in a wet basement, near a swimming pool, or anywhere else that water or moisture are present.

Clean only with a dry cloth and as directed by Audyssey Laboratories, Inc. Unplug this product from the wall outlet before cleaning.

Do not place this product on an unstable cart, stand, tripod, bracket, or table. The product may fall, causing injury to a child or adult, and damage to the product. Use only with a cart, stand, tripod, bracket, or table recommended by the manufacturer, or sold with the product.

Do not block any ventilation openings. Install in accordance with the manufacturer's instructions. To ensure reliable operation of the product and to protect it from overheating, put the product in a position and location that will not interfere with its proper ventilation. For example, do not place the product on a bed, sofa, or similar surface that may block the ventilation openings. Do not put it in a built-in system, such as a bookcase or a cabinet that may keep air from flowing through its ventilation openings.

Do not install near any heat sources, such as radiators, heat registers, stoves, or other apparatus (including amplifiers) that produce heat.

The apparatus shall not be exposed to dripping or splashing and that no objects filled with liquids such as vases shall be placed on the apparatus.

Do not place anything on top of this product.

Protect the power cord from being walked on or pinched by items placed upon or against them, particularly at plugs, convenience receptacles, and the point where they exit from the product. The appliance coupler is used as the disconnect device, the disconnect device shall remain readily operable.

Only use attachments/accessories specified by the manufacturer.

Unplug this apparatus during lightning storms or when unused for long periods of time to prevent damage to this product.

Refer all servicing to qualified service personnel. Servicing is required when the apparatus has been damaged in any way: such as power supply cord or plug is damaged; liquid has been spilled or objects have fallen into the apparatus; the apparatus has been exposed to rain or moisture, does not operate normally, or has been dropped Do not attempt to service this product yourself. Opening or removing covers may expose you to dangerous voltages or other hazards. Please call Audyssey to be referred to an authorized service center near you.

To prevent risk of fire or electric shock, avoid overloading wall outlets, extension cords, or integral convenience receptacles.

Do not let objects or liquids enter the product as they may touch dangerous voltage points or short-out parts that could result in a fire or electric shock and damage to the product.

See product enclosure for safety-related markings.

Use proper power sources. Plug the product into a proper power source, as described in the operating instructions or as marked on the product. This product should be operated only from the type of power source indicated on the marking label. If you are not sure of the type of power supply to your home, consult your local power company.

**FCC WARNING**

This equipment may generate or use radio frequency energy. Changes or modifications to this equipment may cause harmful interference unless the modifications are expressly approved in the manual. The user could lose the authority to operate this equipment if an unauthorized change or modification is made.

**NOTICE (in U.S.A. only)**

This equipment has been tested and found to comply with the limits for a Class 2 digital device, pursuant to Part 15 of the FCC rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses, and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, this is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, you are encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment to an outlet on a different circuit than the one to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

**In Canada:** This Class 2 digital apparatus complies with the Canadian ICES-003.

Audyssey and all other marks used herein are registered trademarks or trademarks of Audyssey Laboratories, Inc.

This product incorporates technology protected under the intellectual property laws of the United States and other countries, including but not limited to pending patents. Any use of this technology without the express written authorization of Audyssey Laboratories, Inc. is strictly prohibited. This product is intended for home and other limited viewing uses only unless otherwise authorized by Audyssey Laboratories, Inc. The purchase and use of this product constitutes acceptance of all of the terms set forth herein.

U.S. and foreign patents pending.
© 2011 Audyssey Laboratories, Inc. All rights reserved.

**Customer Service**
For questions, contact Audyssey at 213-625-4300 or visit
www.audyssey.com/support

**FCC:**

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions:

(1) this device may not cause harmful interference, and

(2) this device must accept any interference received, including interference that may cause undesired operation.

The manufacturer is not responsible for any radio or TV interference caused by unauthorized modifications to this equipment. Such modifications could void the user's authority to operate the equipment.

The antenna used for this transmitter must be installed to provide a separation distance of at least 20 cm from all persons and must not be co-located or operated in conjunction with any other antenna or transmitter.

**IC:**

This device complies with Industry Canada license-exempt RSS standard(s):Operation is subject to the following two conditions:

(1) this device may not cause interference, and

(2) this device must accept any interference, including interference that may cause undesired operation of the device.

**CE:**

Hereby, Audyssey Laboratories Inc, declares that this Audio Dock Air is in compliance with the essential requirements and other relevant provisions of Directive 1999/5/EC.

**IMPORTANT SAFETY INSTRUCTIONS WORLDWIDE (OUTSIDE OF USA, CANADA, AND MEXICO)**

1. **Read these instructions.** All the safety and operating instructions should be read before the product is operated.
2. **Retain these instructions.** The safety and operating instructions should be retained for future use.
3. **Heed all warnings** on the product and in the owner's guide.
4. **Follow instructions.** All operating and use instructions should be followed.
5. Do not use this apparatus near water or moisture. For example, do not use this product near a bathtub, washbowl, kitchen sink, laundry tub, in a wet basement, near a swimming pool, or anywhere else that water or moisture are present.
6. Clean only with a dry cloth and as directed by Audyssey Laboratories, Inc. Unplug this product from the wall outlet before cleaning.
7. Do not place this product on an unstable cart, stand, tripod, bracket, or table. The product may fall, causing injury to a child or adult, and damage to the product. Use only with a cart, stand, tripod, bracket, or table recommended by the manufacturer, or sold with the product.
8. Do not block any ventilation openings. Install in accordance with the manufacturer's instructions. To ensure reliable operation of the product and to protect it from overheating, put the product in a position and location that will not interfere with its proper ventilation. For example, do not place the product on a bed, sofa, or similar surface that may block the ventilation openings. Do not put it in a built-in system, such as a bookcase or a cabinet that may keep air from flowing through its ventilation openings.
9. Do not install near any heat sources, such as radiators, heat registers, stoves, or other apparatus (including amplifiers) that produce heat.
10. The apparatus shall not be exposed to dripping or splashing and that no objects filled with liquids such as vases shall be placed on the apparatus.
11. Do not place anything on top of this product.
12. Protect the power cord from being walked on or pinched by items placed upon or against them, particularly at plugs, convenience receptacles, and the point where they exit from the product. The appliance coupler is used as the disconnect device, the disconnect device shall remain readily operable.
13. Only use attachments/accessories specified by the manufacturer.
14. Unplug this apparatus during lightning storms or when unused for long periods of time to prevent damage to this product.
15. Refer all servicing to qualified service personnel. Servicing is required when the apparatus has been damaged in any way: such as power supply cord or plug is damaged; liquid has been spilled or objects have fallen into the apparatus; the apparatus has been exposed to rain or moisture, does not operate normally, or has been dropped Do not attempt to service this product yourself. Opening or removing covers may expose you to dangerous voltages or other hazards. Please call Audyssey to be referred to an authorized service center near you.
16. To prevent risk of fire or electric shock, avoid overloading wall outlets, extension cords, or integral convenience receptacles.
17. Do not let objects or liquids enter the product as they may touch dangerous voltage points or short-out parts that could result in a fire or electric shock and damage to the product.
18. See product enclosure for safety-related markings.
19. Use proper power sources. Plug the product into a proper power source, as described in the operating instructions or as marked on the product. This product should be operated only from the type of power source indicated on the marking label. If you are not sure of the type of power supply to your home, consult your local power company.

**FCC WARNING**

This equipment may generate or use radio frequency energy. Changes or modifications to this equipment may cause harmful interference unless the modifications are expressly approved in the manual. The user could lose the authority to operate this equipment if an unauthorized change or modification is made.

Audyssey and all other marks used herein are registered trademarks or trademarks of Audyssey Laboratories, Inc.

This product incorporates technology protected under the intellectual property laws of the United States and other countries, including but not limited to pending patents. Any use of this technology without the express written authorization of Audyssey Laboratories, Inc. is strictly prohibited. This product is intended for home and other limited viewing uses only unless otherwise authorized by Audyssey Laboratories, Inc. The purchase and use of this product constitutes acceptance of all of the terms set forth herein. U.S. and foreign patents pending.

© 2012 Audyssey Laboratories, Inc. All rights reserved.

**Customer Service**
For questions, contact Audyssey at www.audyssey.com/support

# Warranty

**LIMITED WARRANTY – UNITED STATES, MEXICO & CANADA**

This product has been designed and manufactured to the highest quality standards. This Limited Warranty on your Audyssey product purchased in the United States, Canada, or Mexico is valid for a period of one year from the date of purchase.

**What is Covered**
Except as specified below, this Limited Warranty covers all parts defective in material or workmanship during the warranty period.

**What We Will Do**
If during the warranty period your Audyssey product is found to be defective, Audyssey will, at our sole option, repair or replace it with a new, used or equivalent product, within a reasonable period of time, without charge for parts or labor.

**Other Warranties**
THIS LIMITED WARRANTY IS IN LIEU OF ALL OTHER EXPRESS WARRANTIES, WRITTEN OR ORAL. ALL IMPLIED WARRANTIES, INCLUDING BUT NOT LIMITED TO ANY WARRANTY OF MERCHANTABILITY OR FITNESS FOR PARTICULAR PURPOSE, ARE LIMITED TO ONE YEAR. Some states do not allow limitations on how long an implied warranty lasts, so the above limitation may not apply to you.

**Limitation of Liability**
OUR LIABILITY IS LIMITED TO THE REPAIR OR REPLACEMENT, AT OUR OPTION, OF ANY DEFECTIVE PRODUCT AND SHALL IN NO EVENT INCLUDE INCIDENTAL OR CONSEQUENTIAL DAMAGES. Some states do not allow the exclusion of incidental or consequential damages, so the above exclusion may not apply to you.

**How to Make a Claim**
Contact Audyssey Laboratories, Inc. at www.audyssey.com/support. If it is found necessary to return the product for repair, you will be given a return authorization number and specific return and shipping instructions which will include but may not be limited to properly packing the product in the original carton for shipping. Cartons not bearing a return authorization number will be refused. To validate your warranty you will need to produce the original sales receipt from an authorized Audyssey dealer/retailer.

**Other Exclusions:**

This Limited Warranty is only valid for the original owner. It is non-transferable.

This Limited Warranty is void if the label bearing the serial number has been removed or defaced, or if the product is not purchased from an authorized Audyssey dealer.

We will not pay for shipping or transportation charges, nor any other costs.

This Limited Warranty does not cover damages that result from:

a. improper or unreasonable use;
b. incorrect installation, connection or packing;
c. removal, transportation and installation of products;
d. any use other than correct use, as described in the user manual;
e. negligence, modifications, unauthorized tampering, alterations or use of parts that are not made or authorized by Audyssey;
f. faulty or unsuitable ancillary equipment;
g. accidents, power surges, act of nature, abuse, misuse, neglect, excess moisture, insects, lighting, water, fire, heat, war, public disturbances or any other cause beyond the reasonable control of Audyssey and its authorized dealers; or
h. repairs or modifications made by an unauthorized person.

**Other Rights**

This Limited Warranty gives you specific legal rights, and you may also have other rights which vary from country to country or state to state.

**LIMITED WARRANTY – WORLDWIDE (EXCEPT UNITED STATES, CANADA AND MEXICO)**

This product has been designed and manufactured to the highest quality standards. This Limited Warranty on your Audyssey product purchased anywhere in the world except the United States, Canada or Mexico is valid for a period of one year from the date of purchase.

**What is Covered**
Except as specified below, this Limited Warranty covers all parts defective in material or workmanship during the warranty period.

**What We Will Do**
If during the warranty period your Audyssey product is found to be defective, Audyssey will, at our sole option, repair or replace it with a new, used or equivalent product, within a reasonable period of time, without charge for parts or labor.

**Other Warranties**
THIS LIMITED WARRANTY IS IN LIEU OF ALL OTHER EXPRESS WARRANTIES, WRITTEN OR ORAL. ALL IMPLIED WARRANTIES, INCLUDING BUT NOT LIMITED TO ANY WARRANTY OF MERCHANTABILITY OR FITNESS FOR PARTICULAR PURPOSE, ARE LIMITED TO ONE YEAR. Some jurisdictions do not allow limitations on how long an implied warranty lasts, so the above limitation may not apply to you.

**Limitation of Liability**
OUR LIABILITY IS LIMITED TO THE REPAIR OR REPLACEMENT, AT OUR OPTION, OF ANY DEFECTIVE PRODUCT AND SHALL IN NO EVENT INCLUDE INCIDENTAL OR CONSEQUENTIAL DAMAGES. Some states do not allow the exclusion of incidental or consequential damages, so the above exclusion may not apply to you.

**How to Make a Claim**
Contact Audyssey Laboratories, Inc. at www.audyssey.com/support or Audyssey Laboratories, Inc. 350 S. Figueroa St., Suite 233, Los Angeles, California 90071 USA. If it is found necessary to return the product for repair, you will be given a return authorization number and specific return and shipping instructions which will include but may not be limited to properly packing the product in the original carton for shipping. Cartons not bearing a return authorization number will be refused. To validate your warranty you will need to produce the original sales receipt from an authorized Audyssey dealer/retailer.

**Other Exclusions:**

1. This Limited Warranty is only valid for the original owner. It is non-transferable.
2. This Limited Warranty is void if the label bearing the serial number has been removed or defaced, or if the product is not purchased from an authorized Audyssey dealer.
3. We will not pay for shipping or transportation charges, nor any other costs.
4. This Limited Warranty does not cover damages that result from:
   a. improper or unreasonable use;
   b. incorrect installation, connection or packing;
   c. removal, transportation and installation of products;
   d. any use other than correct use, as described in the user manual;
   e. negligence, modifications, unauthorized tampering, alterations or use of parts that are not made or authorized by Audyssey;
   f. faulty or unsuitable ancillary equipment;
   g. accidents, power surges, act of nature, abuse, misuse, neglect, excess moisture, insects, lighting, water, fire, heat, war, public disturbances or any other cause beyond the reasonable control of Audyssey and its authorized dealers; or
   h. repairs or modifications made by an unauthorized person.

**Other Rights**

This warranty gives you specific legal rights, and you may have other rights which vary from nation to nation. Consumers have legal rights under applicable national legislation governing the sale of consumer goods. This warranty does not affect those rights.

**Warning:** To reduce the risk of fire or electrical shock, do not expose this appliance to rain or moisture.

**Caution:** To reduce risk of electrical shock, do not remove cover (or back). No user serviceable parts inside. Refer servicing to qualified service personnel.

**For Australia Residents Only**

Our goods come with guarantees that cannot be excluded under the Australian Consumer Law. You are entitled to a replacement or refund for a major failure and for compensation for any other reasonably foreseeable loss or damage. You are also entitled to have the goods repaired or replaced if the goods fail to be of acceptable quality and the failure does not amount to a major failure.

The benefits under Audyssey's warranty are in addition to other rights and remedies under a law in relation to the particular Audyssey product.

©2012 Audyssey Laboratories, Inc. All rights reserved.

"Audyssey" is a registered trademark of Audyssey Laboratories, Inc. U.S. and foreign patents pending.

# AUDYSSEY

## Wireless Speakers

**Quick Start Guide**

**Please get the latest information and full product manual from our website at audyssey.com/support.**

# TOUR THE WIRELESS SPEAKERS



**FRONT**

3.5 mm Headphone Output

Volume Control & Standby Knob

Power LED




**BACK**

Power Cable Plug

Speaker Interconnect Cable Jacks

Bluetooth LED

Bluetooth Pairing Button

3.5 mm Audio Input Jack

# IN THE BOX



Wireless Speakers



## Power Supply
Netzteil
Fuente de alimentación eléctrica
Alimentation électrique
Alimentatore
電源ケーブル

## 3.5 mm Audio Cable
3,5-mm-Audiokabel
Cable de audio de 3,5 mm
Câble audio 3,5 mm
Cavo audio 3,5 mm
3.5 mmオーディオケーブル

## Speaker Interconnect Cable
Lautsprecherkabel
Cable de interconexión de los altavoces
Câble d'interconnexion des haut-parleurs
Cavo di collegamento diffusori
スピーカー相互接続ケーブル

# STEP 1
# CONNECT YOUR SPEAKERS



## Connect your speakers to each other with the supplied Speaker Interconnect Cable.

Verbinden Sie die Lautsprecher mithilfe des mitgelieferten Lautsprecherverbindungskabels miteinander.

Conecte entre sí los altavoces mediante el cable de interconexión suministrado.

Connectez les haut-parleurs à l'aide du câble d'interconnexion des haut-parleurs fourni.

Collegare tra loro i diffusori utilizzando l'apposito cavo fornito.

各スピーカーを付属のスピーカー相互接続ケーブルで接続します。

Подсоедините динамики друг с другом с помощью входящего в комплект поставки соединительного кабеля для динамиков.

# STEP 2
# PLUG IN SPEAKERS



**Connect the Power Supply to the Power Supply Jack on the back of the Audyssey Wireless Speakers.**

**Plug the Power Supply into a power outlet and confirm the Power LED on the front of the right speaker is solid red.**

Schließen Sie das Netzteil an die Stromversorgungsbuchse an der Rückseite der Audyssey Wireless-Lautsprecher an.
Schließen Sie das Netzteil an eine Steckdose an, und vergewissern Sie sich, dass die Betriebs-LED an der Vorderseite des rechten Lautsprechers rot leuchtet.

Conecte la fuente de alimentación eléctrica al conector para alimentación eléctrica de la parte trasera del Altavoz Wireless Audyssey.
Enchufe la fuente de alimentación en una toma de corriente eléctrica y compruebe que el indicador LED de encendido de la parte delantera del altavoz derecho esté iluminado de forma continua en color rojo.

Connectez l'alimentation électrique à la prise d'alimentation électrique à l'arrière du Haut-parleur Wireless Audyssey.
Branchez l'alimentation électrique à une prise murale, et assurez-vous que le voyant d'alimentation placé sur la face avant du haut-parleur de droite reste allumé en rouge.

Collegare l'alimentatore alla presa di alimentazione sul retro del Diffusore Wireless Audyssey.
Inserire l'alimentatore in una presa elettrica e verificare che il LED di alimentazione sul diffusore destro si accenda fisso in rosso.

電源ケーブルをAudyssey Wireless Speaker背面の電源ケーブルコネクターに接続します。
電源ケーブルを電源コンセントに接続して、右側スピーカー正面の電源LEDが赤色に点灯していることを確認します。

Подсоедините источник питания к разъему источника питания на задней панели динамиков Audyssey с функцией Wireless.
Подключите источник питания к розетке. При этом индикатор на передней панели правого динамика должен непрерывно гореть красным цветом.

# STEP 3
# TURN YOUR SPEAKERS ON



**Press the Wireless Speaker Volume Knob to switch your speakers from Standby (solid red Power LED) to On (solid green Power LED).**

Drücken Sie den Wireless-Lautsprecher-Lautstärkeregler, um die Lautsprecher vom Standby-Modus (rot leuchtende Betriebs-LED) in den eingeschalteten Modus (grün leuchtende Betriebs-LED) zu schalten.

Presione el mando de volumen del altavoz Wireless para hacer que los altavoces pasen del modo en espera (indicador LED de encendido de forma continua en color rojo) a estar encendidos (indicador LED de encendido de forma continua en color verde).

Appuyez sur le bouton de contrôle du volume du Haut-parleur Wireless pour passer les haut-parleurs du mode Veille (voyant d'alimentation rouge fixe) au mode Marche (voyant d'alimentation vert fixe).

Premere la manopola volume del diffusore Wireless per accendere i diffusori che passeranno dallo stato standby (LED rosso fisso) allo stato acceso (LED verde fisso).

ボリュームノブを押して、スピーカーをスタンバイ (赤色に点灯) からオン (緑色に点灯) に切り替えます。

Нажмите ручку громкости динамиков с функцией Wireless для перевода динамиков из режима ожидания (непрерывно горит красный индикатор) в рабочее положение (непрерывно горит зеленый индикатор).

# STEP 4
# PAIR YOUR SPEAKERS




**1** **Press the Pairing Button (labeled PAIR) on the back of the right speaker. The speakers will beep twice and the green Bluetooth LED on the back of the right speaker will begin flashing. This indicates that the speakers are ready to pair to your device.**

Drücken Sie die Kopplungstaste (mit PAIR beschriftet) an der Rückseite des rechten Lautsprechers. Die Lautsprecher piepen zweimal und die grüne Bluetooth-LED an der Rückseite des rechten Lautsprechers beginnt zu blinken. Dies weist darauf hin, dass die Lautsprecher zum Koppeln mit dem Gerät bereit sind.

Presione el botón de emparejamiento (que lleva el rótulo "PAIR") situado en la parte trasera del altavoz derecho. Los altavoces emitirán un pitido dos veces y el indicador LED de Bluetooth de color verde situado en la parte trasera del altavoz derecho empezará a titilar, lo que indica que los altavoces están listos para ser emparejados con el dispositivo elegido.

Appuyez sur le bouton de liaison (le bouton PAIR) placé à l'arrière du haut-parleur droit. Les haut-parleurs émettent deux bips sonores, et le voyant Bluetooth vert à l'arrière du haut-parleur droit se met à clignoter, indiquant que les haut-parleurs sont prêts à être liés au dispositif.

Premere il tasto di accoppiamento (etichettato PAIR) sul retro del diffusore destro. I diffusori emetteranno due segnali acustici e il LED verde Bluetooth sul retro del diffusore destro inizierà a lampeggiare a indicare che sono pronti per l'accoppiamento con il dispositivo.

右側スピーカー背面のペアリングボタン (PAIR) を押します。スピーカーから応答音が2回鳴り、右側スピーカー背面の緑色のBluetooth LEDが点滅を開始します。これでスピーカーとご使用のデバイスをペアリングする準備が整いました。

Нажмите кнопку сопряжения (с маркировкой PAIR) на задней панели правого динамика. Из динамиков раздастся двойной сигнал, а зеленый индикатор Bluetooth на задней панели правого динамика начнет мигать. Это свидетельствует о готовности динамиков к сопряжению с устройством.

## 2 Enable Bluetooth on your device.

Aktivieren Sie Bluetooth an Ihrem Gerät.

Habilite Bluetooth en su dispositivo.

Activez Bluetooth sur votre appareil.

Abilitare Bluetooth sul dispositivo.

ご使用のデバイスでBluetoothを有効にします。

Включите на устройстве функцию Bluetooth.




## 3 Select Audyssey Wireless Speakers from the list of available products on your device. If asked to enter a pin, enter "0000" at the prompt. A single beep will let you know that your device has successfully connected and the Bluetooth LED will turn solid green.

Wählen Sie auf dem Gerät den Eintrag Audyssey Wireless-Lautsprecher in der Liste der verfügbaren Produkte aus. Wenn Sie aufgefordert werden, eine PIN einzugeben, geben Sie „0000" ein. Ein einzelner Piepton weist Sie darauf hin, dass das Gerät erfolgreich verbunden wurde, und die Bluetooth-LED leuchtet nun grün.

Seleccione Altavoces Wireless Audyssey en la lista de productos disponibles en el dispositivo. Si se le solicita que introduzca un número "pin", escriba "0000". Un único pitido le indicará que el dispositivo se ha conectado satisfactoriamente; el indicador LED de Bluetooth se iluminará de forma continua en color verde.

Sélectionnez les Haut-parleurs Wireless Audyssey dans la liste des produits disponibles sur votre appareil. Si le système vous demande d'entrer un code PIN, entrez « 0000 » à l'invite. Le système émet un bip sonore pour vous indiquer que la liaison a été établie avec votre appareil, et le voyant Bluetooth passe au vert fixe.

Selezionare i diffusori Wireless Audyssey dall'elenco dei dispositivi disponibili per l'accoppiamento. Se è richiesto un PIN, digitare "0000" nel campo. Un segnale acustico indicherà che l'accoppiamento è avvenuto e il LED Bluetooth si accenderà fisso in verde.

ご使用のデバイスで利用できる製品のリストからAudyssey Wireless Speakersを選択します。パスワードを入力する指示メッセージが表示されたら、「0000」を入力します。応答音が1回鳴ると、ご使用のデバイスが接続された状態となり、Bluetooth LEDが緑色の点灯に変わります。

В списке доступных устройств на Вашем устройстве выберите динамики Audyssey с функцией Wireless. При запросе пароля введите 0000. При успешном подключении прозвучит одиночный сигнал, а индикатор Bluetooth будет непрерывно гореть зеленым цветом.

**NOTE: Your device may require you to manually select the Audyssey Wireless Speakers as the output sound device. For device-specific Bluetooth instructions, please refer to your device's manual. For additional help, visit www.audyssey.com/support.**

HINWEIS: Ihr Gerät verlangt womöglich ein manuelles Auswählen der Audyssey Wireless-Lautsprecher als Ausgabegerät. Für gerätespezifische Bluetooth-Anweisungen lesen Sie die Bedienungsanleitung des Geräts.Weitere Hilfe erhalten Sie unter www.audyssey.com/support.

NOTA: es posible que el dispositivo le obligue a seleccionar manualmente Altavoces Wireless Audyssey como el dispositivo de salida de sonido. Consulte el manual de su dispositivo Bluetooth para obtener las instrucciones específicas sobre el emparejamiento del mismo.

REMARQUE : Votre appareil peut exiger que vous sélectionniez manuellement les Haut-parleurs Wireless Audyssey en tant que périphérique audio de sortie. Pour des instructions Bluetooth propres au périphérique, veuillez vous reporter au manuel de votre appareil. Pour toute assistance, rendez-vous sur la page www.audyssey.com/support.

NOTA: il dispositivo Bluetooth potrebbe richiedere la selezione manuale dei diffusori Wireless Audyssey come periferica di uscita audio. Per istruzioni specifiche su un particolare dispositivo Bluetooth, consultare il manuale fornito con tale dispositivo. Per ulteriore assistenza, visitare www.audyssey.com/support.

注: ご使用のデバイスによっては手動で出力デバイスをAudyssey Wireless Speakersに設定する必要があります。ご使用のデバイス上のBluetooth設定については、デバイスに付属のマニュアルをご参照ください。その他ご不明な点につきましては www.audyssey.com/jp/support をご覧ください。

ВНИМАНИЕ: для использования Вашего устройства может понадобиться вручную выбрать динамики Audyssey с функцией Wireless в качестве устройства вывода звука. Для получения указаний для Вашего устройства с функцией Bluetooth обратитесь к руководству пользователя Вашего устройства Дополнительная информация представлена на сайте www.audyssey.com/support.

# STEP 5
# PLAY

## Music Over the Auxiliary Cable



**Connect the Wireless Speakers to any audio device by using the 3.5 mm Audio Input Jack on the back of the right speaker. An audio cable is provided.**

Verbinden Sie die Audyssey Wireless-Lautsprecher mithilfe des 3,5-mm-Audioeingangs an der Rückseite des rechten Lautsprechers mit Ihrem Audiogerät. Ein Audiokabel ist im Lieferumfang enthalten.

Conecte los Altavoces Wireless Audyssey al dispositivo de audio que desee mediante el conector de entrada de audio de 3,5 mm situada en la parte trasera del altavoz derecho. Utilice el cable de audio suministrado.

Connectez les Haut-parleurs Wireless Audyssey à un appareil audio en utilisant la fiche d'entrée audio 3,5 mm à l'arrière du haut-parleur droit. Un câble audio est fourni.

Collegare i diffusori Wireless Audyssey a un dispositivo audio utilizzando lo spinotto di ingresso audio da 3,5 mm sul retro del diffusore destro. Il cavo audio per questo collegamento è fornito nella dotazione.

付属のオーディオケーブルをを右側スピーカー背面の3.5mmオーディオ入力ジャックに接続し、ご使用のオーディオデバイスと接続します。

Подсоедините динамики Audyssey с функцией Wireless к любому аудиоустройству с помощью гнезда аудиовхода 3,5 мм на задней панели правого динамика. Аудиокабель входит в комплект поставки.

# Listen with Headphones



## Listen to your Wireless Speakers with headphones by plugging in headphones to the 3.5 mm Headphone Output Jack on the front of the speaker.

Hören Sie sich Ihre Musik mittels Kopfhörer über die Wireless-Lautsprecher an, indem Sie die Kopfhörer an die 3,5-mm-Kopfhörerbuchse an der Vorderseite des Lautsprechers anschließen.

Para escuchar los Altavoces Wireless con unos auriculares, enchufe los auriculares en el conector para auriculares de 3,5 mm situado en la parte delantera del altavoz.

Écoutez la musique sur vos Haut-parleurs Wireless au moyen d'un casque que vous aurez préalablement branché à la fiche de sortie du casque 3,5 mm sur la face avant du haut-parleur.

Per ascoltare la musica dai diffusori Wireless con le cuffie, inserire le cuffie nello spinotto di uscita cuffie da 3,5 mm sul fronte del diffusore.

Wirelessスピーカーをヘッドホンで聴くには、ヘッドホンをスピーカー正面の3.5 mmヘッドホン出力ジャックに差し込みます。

Звук из динамиков с функцией Wireless можно прослушивать с помощью наушников. Для этого необходимо подключить наушники в гнездо аудиовыхода 3,5 мм для наушников на передней панели динамика.

# STEP 6
# ADJUST THE VOLUME



**Turn the Volume Knob clockwise to turn up the volume and counter-clockwise to turn down the volume.**

**You can also control your Wireless Speakers' volume from your connected device. For optimal listening experience, it is best to set your volume on your connected device to the maximum listening level and adjust the volume knob on your Wireless Speakers.**

Drehen Sie den Lautstärkeregler im Uhrzeigersinn, um die Lautstärke zu erhöhen, oder gegen den Uhrzeigersinn, um sie zu verringern.
Sie können die Lautstärke der Wireless-Lautsprecher auch über das angeschlossene Gerät regeln. Für ein optimales Hörerlebnis sollten Sie die Lautstärke des angeschlossenen Geräts jedoch auf die maximale Lautstärke einstellen und anschließend mit dem Lautstärkeregler der Wireless-Lautsprecher regeln.

Gire el mando de volumen en el sentido de las agujas del reloj para subir el volumen, y en sentido contrario para bajarlo.
También puede controlar el volumen de los Altavoces Wireless desde el dispositivo conectado (emparejado). Para obtener un sonido óptimo, lo mejor es que ajuste el volumen del dispositivo conectado en el nivel de audición máximo y después ajuste el mando de volumen de los Altavoces Wireless

Tournez le bouton de contrôle du volume dans le sens horaire pour augmenter le volume et dans le sens anti-horaire pour diminuer le volume.
Vous pouvez également contrôler le volume de vos Haut-parleurs Wireless à partir de votre appareil connecté. Pour un confort d'écoute optimal, il est préférable de régler le volume de l'appareil connecté au niveau maximal et d'ajuster le bouton de contrôle du volume sur les Haut-parleurs Wireless.

Ruotare la manopola in senso orario per alzare il volume, ruotarla in senso antiorario per abbassarlo.
È anche possibile regolare il volume dei diffusori Wireless dal dispositivo Bluetooth connesso. Per un'esperienza d'ascolto ottimale, si consiglia di impostare al massimo il volume sul dispositivo Bluetooth connesso e quindi di regolare la manopola volume sui diffusori Wireless.

音量ノブを時計回りに回すと音量が大きくなり、反時計回りに回すと音量が小さくなります。
Wirelessスピーカーの音量は、ご使用の接続デバイスから調整することもできます。最適なリスニングをお楽しみいただくには、ご使用の接続デバイスの音量を最大レベルに設定して、Wirelessスピーカーの音量ノブで調整してください。

Для увеличения громкости поверните ручку громкости по часовой стрелке, а для уменьшения – против часовой стрелки.
Регулировать громкость динамиков с функцией Wireless можно и на подключенном устройстве. Для максимального качества воспроизведения на подключенном устройстве рекомендуется установить максимальную громкость и установить громкость с помощью ручки на динамиках с функцией Wireless.

# HELP

**If you need additional help with your Audyssey Wireless Speakers please visit Ask Audyssey at http://ask.audyssey.com. You can also download the full product manual and reach our support team at www.audyssey.com/support.**

**To reset your speakers' Bluetooth settings follow these steps:**

1. **Press and hold the Pairing Button for five seconds.**
2. **The Bluetooth LED on the back of the speaker will flash rapidly and two low beeps will let you know that your speakers have reset.**

Wenn Sie weitere Hilfe mit den Audyssey Wireless-Lautsprechern benötigen, besuchen Sie „Ask Audyssey" unter http://ask.audyssey.com. Unter www.audyssey.com/support können Sie sich auch die vollständige Bedienungsanleitung des Produkts herunterladen und unser Support-Team kontaktieren.

Zum Zurücksetzen der Bluetooth-Einstellungen der Lautsprecher gehen Sie wie folgt vor:

1. Halten Sie die Kopplungstaste fünf Sekunden lang gedrückt.
2. Die Bluetooth-LED an der Rückseite der Lautsprecher blinkt schnell und es werden zwei tiefe Pieptöne ausgegeben, um Sie darüber zu informieren, dass die Lautsprecher zurückgesetzt wurden.

Si necesita ayuda adicional para usar los Altavoces Wireless Audyssey, visite el sitio web de Ask Audyssey en http://ask.audyssey.com. También puede descargar el manual completo del producto o solicitar ayuda a nuestro equipo de asistencia en www.audyssey.com/support.

Si necesita restablecer la configuración de Bluetooth de los altavoces, siga estos pasos:

1. Mantenga presionado durante cinco segundos el botón de emparejamiento.
2. El indicador LED de Bluetooth situado en la parte trasera del altavoz parpadeará con rapidez y escuchará dos pitidos bajos, indicativos de que se ha restablecido la configuración de los altavoces.

Si vous avez besoin d'aide supplémentaire avec vos Haut-parleurs Wireless Audyssey, accédez à la page http://ask.audyssey.com, et cliquez sur Ask Audyssey. Vous pouvez aussi télécharger l'intégralité du manuel du produit et vous adresser à notre service d'assistance sur www.audyssey.com/support.

Pour réinitialiser les réglages Bluetooth de vos haut-parleurs, procédez comme suit :

1. 1. Appuyez sur le bouton de liaison, et maintenez-le enfoncé pendant cinq secondes.
2. 2. Le voyant Bluetooth à l'arrière du haut-parleur clignote rapidement, et deux bips sonores vous indiquent que les haut-parleurs ont été réinitialisés.

Per assistenza con i diffusori Wireless Audyssey, visitare Ask Audyssey all'indirizzo http://ask.audyssey.com, da cui è anche possibile scaricare il manuale completo del prodotto e contattare il team dell'assistenza (www.audyssey.com/support).

Per ripristinare le impostazioni predefinite Bluetooth dei diffusori:

1. Tenere premuto il tasto di accoppiamento per cinque secondi.
2. Il LED Bluetooth sul retro del diffusore destro lampeggerà velocemente e due segnali acustici di tono basso indicheranno quando la reimpostazione è avvenuta.

製品についてその他ご不明な点につきましては www.audyssey.com/jp/support より製品マニュアルのダウンロード、または弊社サポートチームにお問い合わせください。

ご使用のスピーカーのBluetooth設定をリセットするには、以下のステップに従ってください。

1. ペアリングボタンを5秒間長押しします。
2. スピーカー背面のBluetooth LEDが素早く点滅して、低い応答音が2回鳴ると、ご使用のスピーカーがリセットされた状態になります。

Для получения дополнительных сведений о динамиках Audyssey с функцией Wireless посетите сайт Ask Audyssey (Задайте вопрос Audyssey) по адресу http://ask.audyssey.com. Скачать полное руководство пользователя и получить помощь можно на сайте www.audyssey.com/support.

Для сброса настроек динамиков с функцией Bluetooth выполните следующую процедуру:

1. Нажмите и удерживайте в течение пяти секунд кнопку сопряжения.
2. Индикатор Bluetooth на задней панели динамика начнет часто мигать, а затем прозвучат два сигнала, свидетельствующие о выполнении сброса установок.

FCC:
This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions:
(1) this device may not cause harmful interference, and
(2) this device must accept any interference received, including interference that may cause undesired operation.
The manufacturer is not responsible for any radio or TV interference caused by unauthorized modifications to this equipment. Such modifications could void the user's authority to operate the equipment.
The antenna used for this transmitter must be installed to provide a separation distance of at least 20 cm from all persons and must not be co-located or operated in conjunction with any other antenna or transmitter.

IC:
This device complies with Industry Canada licence-exempt RSS standard(s). Operation is subject to the following two conditions:
(1) this device may not cause interference, and
(2) this device must accept any interference, including interference that may cause undesired operation of the device.

Le présent appareil est conforme aux CNR d'Industrie Canada applicables aux appareils radio exempts de licence. L'exploitation est autorisée aux deux conditions suivantes :
(1) l'appareil ne doit pas produire de brouillage, et
(2) l'utilisateur de l'appareil doit accepter tout brouillage radioélectrique subi, même si le brouillage est susceptible d'en compromettre le fonctionnement.

CE:
Hereby, Audyssey Laboratories Inc, declares that these Wireless Speakers are in compliance with the essential requirements and other relevant provisions of Directive 1999/5/EC.

Audyssey designs innovative audio technologies and products for you: the music fanatic, film buff and audiophile.

You can find Audyssey everywhere: cinemas, mobile devices, televisions, cars and home theaters. Our products are engineered for clarity, depth and superior sound quality–just as the artist intended.

AUDYSSEY
www.audyssey.com

# OUR PRODUCTS

## THE AUDIO DOCK

**Unbelievable sound.** You'll want to crank up the volume and enjoy its crystal clear bass!

**Does it all.** Sync, charge & wirelessly stream music. It's a speakerphone too.

## THE AUDIO DOCK AIR

**Boastful bass.** Equipped with a passive bass radiator for deep powerful bass warm mids and crisp highs.

**Music's in the air.** Stream music wirelessly with AirPlay® to enjoy music in every room.

## THE WIRELESS SPEAKERS

**Bluetooth.** Stream from your smartphone, tablet, iPod®... almost anything.

**Audyssey technology.** Audyssey EQ and BassXT deliver flawless sound and deep, rich bass.

*Available at audyssey.com/store and many other fine retailers.*

*As Featured in:*

The New York Times GIZMODO engadget MAXIM POPSCI uncrate THRILLIST

AC-CRD-2011-2 RevA6

# Audyssey Warranty and Safety Information

## LIMITED WARRANTY – UNITED STATES, MEXICO & CANADA

This product has been designed and manufactured to the highest quality standards. This Limited Warranty on your Audyssey product purchased in the United States, Canada, or Mexico is valid for a period of one year from the date of purchase.

### What is Covered

Except as specified below, this Limited Warranty covers all parts defective in material or workmanship during the warranty period.

### What We Will Do

If during the warranty period your Audyssey product is found to be defective, Audyssey will, at our sole option, repair or replace it with a new, used or equivalent product, within a reasonable period of time, without charge for parts or labor.

### Other Warranties

THIS LIMITED WARRANTY IS IN LIEU OF ALL OTHER EXPRESS WARRANTIES, WRITTEN OR ORAL. ALL IMPLIED WARRANTIES, INCLUDING BUT NOT LIMITED TO ANY WARRANTY OF MERCHANTABILITY OR FITNESS FOR PARTICULAR PURPOSE, ARE LIMITED TO ONE YEAR. Some states do not allow limitations on how long an implied warranty lasts, so the above limitation may not apply to you.

### Limitation of Liability

OUR LIABILITY IS LIMITED TO THE REPAIR OR REPLACEMENT, AT OUR OPTION, OF ANY DEFECTIVE PRODUCT AND SHALL IN NO EVENT INCLUDE INCIDENTAL OR CONSEQUENTIAL DAMAGES. Some states do not allow the exclusion of incidental or consequential damages, so the above exclusion may not apply to you.

### How to Make a Claim

Contact Audyssey Laboratories, Inc. at www.audyssey.com/

support. If it is found necessary to return the product for repair, you will be given a return authorization number and specific return and shipping instructions which will include but may not be limited to properly packing the product in the original carton for shipping. Cartons not bearing a return authorization number will be refused. To validate your warranty you will need to produce the original sales receipt from an authorized Audyssey dealer/retailer.

**Other Exclusions:**

This Limited Warranty is only valid for the original owner. It is non-transferable.

This Limited Warranty is void if the label bearing the serial number has been removed or defaced, or if the product is not purchased from an authorized Audyssey dealer.

We will not pay for shipping or transportation charges, nor any other costs.

This Limited Warranty does not cover damages that result from:

improper or unreasonable use;

incorrect installation, connection or packing;

removal, transportation and installation of products;

any use other than correct use, as described in the user manual;

negligence, modifications, unauthorized tampering, alterations or use of parts that are not made or authorized by Audyssey;

faulty or unsuitable ancillary equipment;

accidents, power surges, act of nature, abuse, misuse, neglect, excess moisture, insects, lighting, water, fire, heat, war, public disturbances or any other cause beyond the reasonable control of Audyssey and its authorized dealers; or

repairs or modifications made by an unauthorized person.

**Other Rights**

This Limited Warranty gives you specific legal rights, and you may also have other rights which vary from country to country or state to state.

**Warning:** To reduce the risk of fire or electrical shock, do not expose this appliance to rain or moisture.

**Caution:** To reduce risk of electrical shock, do not remove cover (or back). No user serviceable parts inside. Refer servicing to qualified service personnel.

**Important Safety Instructions**

**Read these instructions.** All the safety and operating instructions should be read before the product is operated.

**Retain these instructions.** The safety and operating instructions should be retained for future use.

**Heed all warnings** on the product and in the owner's guide.

**Follow instructions.** All operating and use instructions should be followed.

Do not use this apparatus near water or moisture. For example, do not use this product near a bathtub, washbowl, kitchen sink, laundry tub, in a wet basement, near a swimming pool, or anywhere else that water or moisture are present.

Clean only with a dry cloth and as directed by Audyssey Laboratories, Inc. Unplug this product from the wall outlet before cleaning.

Do not place this product on an unstable cart, stand, tripod, bracket, or table. The product may fall, causing injury to a child or adult, and damage to the product. Use only with a cart, stand, tripod, bracket, or table recommended by the manufacturer, or sold with the product.

Do not block any ventilation openings. Install in accordance

with the manufacturer's instructions. To ensure reliable operation of the product and to protect it from overheating, put the product in a position and location that will not interfere with its proper ventilation. For example, do not place the product on a bed, sofa, or similar surface that may block the ventilation openings. Do not put it in a built-in system, such as a bookcase or a cabinet that may keep air from flowing through its ventilation openings.

Do not install near any heat sources, such as radiators, heat registers, stoves, or other apparatus (including amplifiers) that produce heat.

The apparatus shall not be exposed to dripping or splashing and that no objects filled with liquids such as vases shall be placed on the apparatus.

Do not place anything on top of this product.

Protect the power cord from being walked on or pinched by items placed upon or against them, particularly at plugs, convenience receptacles, and the point where they exit from the product. The appliance coupler is used as the disconnect device, the disconnect device shall remain readily operable.

Only use attachments/accessories specified by the manufacturer.

Unplug this apparatus during lightning storms or when unused for long periods of time to prevent damage to this product.

Refer all servicing to qualified service personnel. Servicing is required when the apparatus has been damaged in any way: such as power supply cord or plug is damaged; liquid has been spilled or objects have fallen into the apparatus; the apparatus has been exposed to rain or moisture, does not operate normally, or has been dropped Do not attempt to service this product yourself. Opening or removing covers may expose you to dangerous voltages or other hazards. Please call Audyssey to be referred to an authorized service center near you.

To prevent risk of fire or electric shock, avoid overloading wall outlets, extension cords, or integral convenience receptacles.

Do not let objects or liquids enter the product as they may touch dangerous voltage points or short-out parts that could result in a fire or electric shock and damage to the product.

See product enclosure for safety-related markings.

Use proper power sources. Plug the product into a proper power source, as described in the operating instructions or as marked on the product. This product should be operated only from the type of power source indicated on the marking label. If you are not sure of the type of power supply to your home, consult your local power company.

**FCC WARNING**

This equipment may generate or use radio frequency energy. Changes or modifications to this equipment may cause harmful interference unless the modifications are expressly approved in the manual. The user could lose the authority to operate this equipment if an unauthorized change or modification is made.

**NOTICE (in U.S.A. only)**

This equipment has been tested and found to comply with the limits for a Class 2 digital device, pursuant to Part 15 of the FCC rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses, and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, this is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, you are encouraged to try to correct the interference by one or more of the following measures:

Reorient or relocate the receiving antenna.

Increase the separation between the equipment and receiver.

Connect the equipment to an outlet on a different circuit than the one to which the receiver is connected.

Consult the dealer or an experienced radio/TV technician for help.

**In Canada:** This Class 2 digital apparatus complies with the Canadian ICES-003.

Audyssey and all other marks used herein are registered trademarks or trademarks of Audyssey Laboratories, Inc.

This product incorporates technology protected under the intellectual property laws of the United States and other countries, including but not limited to pending patents. Any use of this technology without the express written authorization of Audyssey Laboratories, Inc. is strictly prohibited. This product is intended for home and other limited viewing uses only unless otherwise authorized by Audyssey Laboratories, Inc. The purchase and use of this product constitutes acceptance of all of the terms set forth herein.

U.S. and foreign patents pending.
© 2011 Audyssey Laboratories, Inc. All rights reserved.

**Customer Service**
For questions, contact Audyssey at 213-625-4300 or visit www.audyssey.com/support

## MEXICO

### GARANTÍA LIMITADA – ESTADOS UNIDOS, MÉXICO Y CANADÁ

Este producto fue diseñado y fabricado con los estándares de calidad más altos. Esta Garantía limitada en su producto Audyssey comprado en los Estados Unidos, Canadá o México es válida por un año a partir de la fecha de compra.

**Cuál es la cobertura**

Excepto por lo especificado a continuación, esta Garantía limitada cubre todas las piezas defectuosas en el material o la mano de obra durante el período de garantía.

**Qué haremos**

Si durante el período de garantía se determina que el producto de Audyssey es defectuoso, Audyssey lo reparará o reemplazará, a su exclusivo criterio, con un producto nuevo, usado o equivalente, dentro de un período de tiempo razonable, sin cargo por las piezas o la mano de obra.

**Otras garantías**

ESTA GARANTÍA LIMITADA SUSTITUYE CUALQUIER OTRA GARANTÍA EXPRESA, ESCRITA U ORAL. TODAS LAS GARANTÍAS IMPLÍCITAS, INCLUIDAS, ENTRE OTRAS, LA GARANTÍA DE COMERCIABILIDAD O IDONEIDAD PARA UN FIN EN PARTICULAR, SE LIMITAN A UN AÑO. Algunos estados no admiten limitaciones sobre la duración de una garantía implícita, por lo que es posible que la limitación anterior no le concierna.

**Limitación de responsabilidad**

NUESTRA RESPONSABILIDAD SE LIMITA A LA REPARACIÓN O AL REEMPLAZO, A NUESTRO CRITERIO, DE CUALQUIER PRODUCTO DEFECTUOSO Y NO INCLUIRÁ EN NINGÚN CASO DAÑOS INCIDENTALES O EMERGENTES. Algunos estados no admiten la exclusión de daños incidentales o emergentes, por lo que es posible que la exclusión anterior no le concierna.

**Cómo efectuar un reclamo**

**AVERTISSEMENT RELATIF AU REGLEMENT DE LA FCC**

Cet équipement peut générer ou utiliser de l'énergie de fréquence radio. Toute modification apportée à cet équipement, autre que celles expressément autorisées dans le manuel, peut provoquer des interférences nuisibles. L'utilisateur peut perdre son droit d'utiliser cet équipement s'il effectue une modification non autorisée.

**REMARQUE (pour les Etats-Unis uniquement)**

Cet équipement a été testé et déclaré conforme aux limites applicables à un appareil numérique de Classe 2, suivant l'article 15 du règlement de la FCC. Ces limites sont conçues en vue de prévoir une protection raisonnable contre les interférences nuisibles au sein d'une installation domestique. Cet équipement génère, utilise et peut émettre de l'énergie de fréquence radio et, s'il n'est pas installé et utilisé conformément aux instructions, il peut produire des interférences nuisibles aux communications radio. Toutefois, il n'est pas garanti que des interférences ne se produiront pas au sein d'une installation particulière. Si cet équipement produit effectivement des interférences nuisibles à la réception radio ou télévision, ce qui est vérifiable en allumant puis éteignant l'équipement, nous vous recommandons de tenter de corriger ces interférences à l'aide d'une ou de plusieurs des mesures suivantes :

Modifiez l'orientation ou l'emplacement de l'antenne de réception.

Eloignez davantage l'équipement du récepteur.

Branchez l'équipement sur une prise fonctionnant sur un circuit différent de celui sur lequel le récepteur est branché.

Adressez-vous à votre concessionnaire ou à un technicien radio/TV expérimenté pour obtenir de l'aide.

**Au Canada :** cet appareil numérique de Classe 2 est conforme à la norme canadienne ICES-003.

Audyssey, et toutes les autres marques utilisées dans le présent document sont des marques déposées ou des marques commerciales de Audyssey Laboratories, Inc.

Ce produit intègre une technologie protégée par les lois sur la propriété intellectuelle des Etats-Unis et d'autres pays, y compris, sans s'y limiter, les brevets en attente. Toute utilisation de cette technologie sans l'autorisation expresse et écrite de Audyssey Laboratories, Inc. est strictement interdite. Ce produit est conçu pour être utilisé au sein du domicile et dans le cadre d'autres utilisations restreintes, sauf autorisation expresse de Audyssey Laboratories, Inc. L'achat et l'utilisation de ce produit impliquent l'acceptation de l'ensemble des conditions définies dans le présent document.

Brevets en attente aux Etats-Unis et à l'étranger.

© 2011 Audyssey Laboratories, Inc. Tous droits réservés.

**Service Client**

Pour toutes questions, veuillez prendre contact avec Audyssey et consultez le site www.audyssey.com/support.

Part Number: AC-W-2011-0
Description: Warranty booklet, North America, A7, black & white, 19 pages